

ORIGINAL



RETROFIT

All the Parts You Need... Before You Need Them!

# PARTS REFERENCE GUIDE FOR **Rectangular Recessed Wet Well Mounted Pump Stations**



## Your Helpful Parts Resource

For S&L Product codes: 18

(First Two Numbers of Station Serial Number)

**Smith & Loveless, Inc.**  
[www.smithandloveless.com](http://www.smithandloveless.com)

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 1

## After Market Parts Catalog

# Rectangular Recessed Wet Well Mounted Pump Stations

S&L Product codes: 18 (First Two Letters of Station Serial Number)

## ALPHABETICAL PARTS LISTING

PART NAME	PAGE
AIR-VACUUM PRESSURE GAUGES .....	34
ALARM LIGHT .....	8, 32
ALARM, PUMP FAILURE .....	11
ALARMS.....	32
AUXILIARY CONTACTS.....	8
AUXILIARY HEATER.....	9
BLOWER .....	32
BLOWER CORD .....	32
BREAKERS .....	17-22
CHECK VALVES, FLOAT .....	39
CHECK VALVES, WAFER .....	44
COMBINED EXHAUST ASSEMBLY- VACUUM PUMP .....	42
COMBO, AIR-VACUUM GAUGE .....	33
CONTACTS, AUXILIARY .....	8
CONTACTORS.....	8
CONTROLLER .....	8, 10
CORD CONNECTOR, FLOAT SWITCH .....	9
DISPLACEMENT (FLOAT) SWITCH .....	9, 12
DISPLAY FUSE .....	8
DISPLAY SCREEN .....	9, 33
DOME, ELECTRODE.....	39
DOME ASSEMBLY, ELECTRODE .....	39
DOUBLE BALANCED (High Head) MECHANICAL SEALS.....	30
ELBOW, PIPING .....	23-28
EXPANSION CARD.....	10
FERRULE NUT & SLEEVE .....	42
FIBERGLASS REPAIR KIT FOR HOOD .....	35
FILTERS, VAPOR .....	42
FITTINGS FOR TUBING .....	42
FLANGE GASKET .....	33
FLOAT (DISPLACEMENT) SWITCHES .....	9, 12

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 2

<u>PART NAME</u>	<u>PAGE</u>
------------------	-------------

FLOAT SWITCH CONNECTION PLATE .....	36
FLOAT (DISPLACEMENT) SWITCH, CORD CONNECTOR .....	9
FLOAT CHECK VALVES .....	39
FRONT HEADS & VOLUTES, INTEGRAL .....	26-28
FUSE, DISPLAY .....	8
GASKETS .....	31
GASKETS, FORM-A .....	32
GASKETS, VOLUTE .....	31
GAUGES, PRESSURE .....	33
GFCI RECEPTACLES .....	9
GLOBE, RED & GAURD .....	32
HEATER .....	9
HMI MESSAGE PANEL SCREENS .....	33, 34
H-O-A SWITCH .....	12
HOODS .....	34
HOODS, MISCELLANEOUS PARTS .....	34
HOOD (FIBERGLASS) REPAIR KIT .....	35
HORN, ALARM .....	32
HOW TO CHANGE YOUR SINGLE MECHANICAL SEAL VIDEO .....	37
IMPELLER BOLTS & WASHERS .....	26-28
IMPELLERS .....	31
IMPELLER, X-PELLER® .....	31
INTEGRAL VOLUTE & FRONT HEAD .....	26-28
KEYSTOCK (MOTOR SHAFT KEY) .....	35
LABELS .....	35
LATCHES, FOR LOCKS .....	35
LEVEL INDICATION CONNECTION PLATE .....	36
LIFTING STANCHION .....	36
LIGHT .....	32
LIGHT, ALARM .....	8
LIGHTNING PROTECTION .....	10
LIMIT SWITCH .....	12
LINE STRAINER .....	36
LOCK LATCHES .....	35
LOUVER, VENT .....	37
MECHANICAL SEAL .....	29
MECHANICAL SEAL VIDEO – TRAINING ON HOW TO CHANGE .....	37
MONITOR RELAY, PHASE .....	10
MOTOR ADAPTERS .....	23-28
MOTOR SHAFT KEYSTOCK .....	35

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 3

<u>PART NAME</u>	<u>PAGE</u>
------------------	-------------

MOTORS .....	•18
PAINT .....	•37
PHASE MONITOR RELAYS .....	•10
PLUG VALVES .....	•43
PLUG VALVE HANDLE/WRENCH .....	•43
POWER SUPPLY .....	•10
PRESSURE TRANSDUCERS/SENSORS, SUBMERSIBLE .....	•10
PROTECTION, LIGHTNING .....	•10
<b>PROTRONIX® I</b> .....	•8, 10
<b>PROTRONIX® II</b> .....	•8, 10
PUMP FAILURE ALARM .....	•11
PUMP IMPELLER .....	•31
PUMP MOTORS .....	•18
RELAY .....	•11
RELAY, ELECTRODE .....	•39
RELAYS, PHASE MONITOR .....	•10
RESISTOR .....	•11
ROLLER TRACK & PARTS FOR HOOD .....	•34
SCREEN, DISPLAY .....	•9, 33
SEALS, MECHANICAL .....	•29
<b>SHADE-AIDE™</b> .....	•37
SINGLE MECHANICAL SEAL .....	•29
SLINGER RINGS (for Motor Shaft) .....	•37
SOLENOID VALVES .....	•43
<b>SONIC START® KITS</b> .....	•39
<b>SONIC START® OPERATING MODULE</b> .....	•39
<b>SONIC START® PROBE</b> .....	•39
<b>SONIC START® REPLACEMENT PARTS</b> .....	•40
SPRING LOADED WAFER CHECK VALVE .....	•44
SPRING LOADED WAFER CHECK VALVE SPARE PARTS .....	•44
STARTERS, IEC RATED .....	•13
STARTERS, NEMA RATED .....	•14
SUCTION PIPING .....	•23-28
SWITCHES .....	•12
SWITCHES, FLOAT - DISPLACEMENT .....	•9, 12
SWITCHES, FLOAT CORD CONNECTOR .....	•9
TEE .....	•23-28
TEMPERATURE TRANSMITTER .....	•9, 12
TOUCH-UP PAINT, <b>VERSAPOX®</b> .....	•37
TRANSFORMER .....	•12

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 4

<u>PART NAME</u>	<u>PAGE</u>
TRANSDUCER, SUBMERSIBLE PRESSURE.....	•10
TUBING, VACUUM .....	•42
TWO-WAY SOLENOID VALVE.....	•39
VACUUM-AIR PRESSURE GAUGES.....	•34
VACUUM DOME .....	•40
VACUUM DOME ASSEMBLY .....	•40
VACUUM PUMP – SINGLE PISTON .....	•41
VACUUM PUMP – SINGLE PISTON SPARE PARTS.....	•41
VACUUM PUMP – DUAL PISTON .....	•41
VACUUM PUMP – DUAL PISTON SPARE PARTS .....	•41
VACUUM PUMP-COMBINED EXHAUST ASSEMBLY.....	•42
VACUUM TUBING .....	•42
VACUUM TUBING FITTINGS .....	•42
VALVES, PLUG .....	•43
VALVES, SOLENOID .....	•43
VALVES, WAFER CHECK.....	•44
VALVES, WAFER CHECK SPARE PARTS.....	•44
VALVE WRENCH.....	•44
VAPOR FILTERS .....	•42
VENT LOUVER .....	•37
VENTILATION .....	•32
<b>VERSAPOX®</b> , TOUCH-UP PAINT .....	•37
VIDEO, TRAINING.....	•37
VOLUTE GASKETS .....	•32
VOLUTES & FRONT HEAD, INTEGRAL .....	•26-28
WAFER CHECK VALVES .....	•44
WAFER CHECK VALVE SPARE PARTS .....	•44
WET WELL MANWAY ACCESS LIDS - 4' WET WELL .....	•38
WET WELL MANWAY ACCESS LIDS – 5' & 6' WET WELL .....	•38
WRENCH, VALVE.....	•44
<b>X-PELLER®</b> IMPELLER .....	•31

[After Market Parts Catalog](#)

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 5

## Rectangular Recessed Wet Well Mounted Pump Stations

S&L Product codes: 18 (First Two Letters of Station Serial Number)

PART	PAGE
------	------

### ELECTRICAL COMPONENTS

ALARM LIGHT - RED .....	8
AUXILIARY CONTACTS.....	8
CONTROLLER.....	8
DISPLAY FUSE .....	8
DISPLAY SCREEN .....	9
FLOAT DISPLACEMENT SWITCHES, BACKUP .....	9
FLOAT SWITCH, COAD CONNECTOR.....	9
GROUND FAULT CIRCUIT INTERRUPTER RECEPTACLE .....	9
HEATER .....	9
EXPANSION CARD.....	10
LIGHTNING PROTECTION .....	10
PHASE MONITOR RELAYS .....	10
POWER SUPPLY – 24 VOLT .....	10
PRESSURE TRANSDUCERS/SENSORS, SUBMERSIBLE .....	10
PROTRONIX® CONTROLLER .....	10
PUMP FAILURE ALARM .....	11
RELAYS .....	11
RESISTOR .....	11
SOLENOID VALVE, 2-WAY LARGE PORT .....	11
SWITCHES .....	12
TEMPERATURE TRANSMITTER .....	12
TRANSFORMER.....	12
STARTERS & MOTOR CIRCUIT PROTECTORS – IEC .....	13
STARTERS & MOTOR CIRCUIT PROTECTORS – NEMA .....	14-16
OVERLOAD COILS I.E.C. & NEMA STARTERS.....	16
BREAKERS- "THREE PHASE MOTOR CIRCUIT BREAKER".....	17
BREAKERS- "SINGLE PHASE MOTOR CIRCUIT BREAKER".....	17
BREAKERS-MOTORS-VERTICAL "P".....	18
BREAKERS – "QUICKLAG C" TYPE .....	19-21
BREAKERS – "THERMAL MAGNETIC " TYPE EHD .....	22
BREAKERS – "MCP MOTOR CIRCUIT PROTECTOR .....	22
MOTORS .....	17

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 6

## PART

## PAGE

### **MECHANICAL, PIPING, & PARTS**

#### **PUMP PARTS**

*Includes: shaft diameter, impeller, maximum diameter, Suction Side - Diameter Eye, front head, pump stand, volute, gaskets, motor adapter, impeller bolt, impeller washer.*

4B2B*1, 4B2D.....	23
4B3B, 4C2B.....	24
4C2D.....	25
4C3B, 4D3B.....	26
4B2X*1, 4C2X.....	27
6B3B, 6C3B, 6D3B.....	28

#### **MECHANICAL SEALS**

B-SHAFT (1 $\frac{1}{8}$ ) (Seals & Spare Parts).....	29
C-SHAFT (2 $\frac{1}{8}$ ) (Seals & Spare Parts).....	29
D-SHAFT (3") (Seals & Spare Parts).....	29
DOUBLE BALANCED (High Head) MECHANICAL SEALS.....	30

VOLUTE GASKETS.....	31
---------------------	----

IMPELLERS.....	31
----------------	----

X-PELLER® IMPELLERS.....	31
--------------------------	----

### **OTHER PARTS**

ALARMS .....	32
BLOWER - VENTILATION .....	32
FORM-A-GASKET .....	32
GASKETS .....	33
GAUGES, COMBO VACUUM-AIR.....	34
HMI MESSAGE PANEL SCREENS .....	33
HOODS .....	34
HOODS – MISCELLANEOUS PARTS.....	34
HOOD (FIBERGLASS) REPAIR KIT .....	35
KEYSTOCK .....	35

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 7

## PART

## PAGE

### OTHER PARTS

LABELS .....	35
LATCHES, FOR LOCKS.....	35
LEVEL INDIVIDUAL CONNECTION PLATE .....	36
LIFTING STANCHION.....	36
LINE STRAINER.....	36
LOUVER, VENT.....	36
PAINT ( <b>VERSAPOX®</b> ) & TOUCH-UP KITS.....	37
<b>SHADE-AIDE™</b> .....	37
SLINGER RINGS (for Motor Shaft).....	37
VENT LOUVER.....	37
VIDEOS - TRAINING.....	37
4' WET WELL MANWAY ACCESS LIDS (ALUMINUM).....	38
5' & 6' WET WELL MANWAY ACCESS LIDS (ALUMINUM).....	38

### VACUUM PRIMING SYSTEM

FLOAT CHECK VALVES .....	39
SOLENOID VALVES .....	39
<b>SONIC START® STREAMLINE™ KITS</b> .....	39
<b>SONIC START® STREAMLINE™ PROBE</b> .....	39
<b>SONIC START® STREAMLINE™ REPLACEMENT PARTS</b> .....	40
VACUUM DOME .....	40
VACUUM DOME ASSEMBLY .....	40
VACUUM PUMP – HEAVY DUTY – SINGLE PISTON & SPARE PARTS .....	41
VACUUM PUMP – HEAVY DUTY – DUAL PISTON & SPARE PARTS .....	41
VACUUM PUMP – COMBINED EXHAUST ASSEMBLY .....	42
VACUUM TUBING .....	42
VACUUM TUBING FITTINGS .....	42
VAPOR FILTER .....	42

### VALVES

PLUG VALVES .....	43
SOLENOID VALVES .....	43
WAFER CHECK VALVES, SPRING LOADED .....	44
WAFER CHECK VALVES, 4" & 6", SPARE PARTS .....	44
WRENCH, VALVE .....	44

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 8

## ELECTRICAL COMPONENTS

### ALARM LIGHT - RED

#### PART DESCRIPTION

#### PART #

Alarm Light – Complete Assembly - Red, 120V	28B580B
Body Fixture – Alarm Light	5L76
Adapter – Alarm Light	5L77
Globe – Alarm Light	5L78B
Guard – Alarm Light	5L79
Bulb – 12 Volt	4L120
Bulb – 115 Volt	4L95A

### AUXILIARY CONTACTS

#### PART DESCRIPTION

#### PART #

Auxiliary Contacts one (1) NO (Normally Open)	4L560A
Auxiliary Contacts one (1) NC (Normally Closed)	4L560B
Auxiliary Contacts one (1) NO (Normally Open) & one (1) NC (Normally Closed)	4L560C
Auxiliary Contacts two (2) NO (Normally Open)	4L560D

### CONTACTORS

Not descriptive enough. Ask customer if they mean contact terminal block, Auxiliary Relay, Starter, etc.

### CONTROLLER – PROTRONIX®

#### PART DESCRIPTION

#### PART #

PROTRONIX® I Controller – 4L536A, 4L536B <i>(SOLD THRU RETROFIT ONLY)</i>	Call Retrofits
PROTRONIX® II Controller – 4L536C-1 <i>(SOLD THRU RETROFIT ONLY)</i>	Call Retrofits

### DISPLAY FUSE

#### PART DESCRIPTION

#### PART #

Fuse, FNQ, 1 AMP	4L371A
Fuse, FNQ-R, 1/2 AMP	4L371T

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 9

## ELECTRICAL COMPONENTS (CONTINUED)

### DISPLAY SCREEN

#### PART DESCRIPTION

#### PART #

Display Screen – HMI – Color Touch Screen - 4L523F – current- (*SOLD THRU RETROFIT ONLY*) Replaces 4L53C & 4L523E

Call Retrofit

Display Screen – HMI – 2-line LED – 4L523D – obsolete (*SOLD THRU RETROFIT ONLY*)

Call Retrofit

Display Screen – HMI – 4-line LED – 4L523B – obsolete (*SOLD THRU RETROFIT ONLY*)

Call Retrofit

Display Screen – HMI – Monochrome Touch Screen – 4L523E – obsolete (*SOLD THRU RETROFIT ONLY*)

Call Retrofit

Communication Cable (**PROTRONIX® II** to HMI) 536C-4

Call Retrofit

### FLOAT (DISPLACEMENT) SWITCHES, BACKUP

Serve as Backup to the Submersible Pressure Transducer

#### PART DESCRIPTION

#### PART #

Float Switch (P/N 87A80 Obsolete, Replaced by 4L291A)

4L291A

Float Switch (Normally Open **Blue**), 30 ft. cord

4L291A

Float Switch (Normally Closed **Red**), 30 ft. cord

4L291B

Float Switch (Normally Open **Blue**), 45 ft. cord

4L291C

Submersible Pressure Transducer – Wet Well Level Sensor – 30' Cord  
hangs down inside of wet well. (*Replaces 4L563C*).

4L563J

### FLOAT SWITCH, CORD CONNECTOR

#### PART DESCRIPTION

#### PART #

Cord Connector, Float Switch Adjustment

5L57C

### GROUND FAULT CIRCUIT INTERRUPTER (GFCI) RECEPTACLES

#### PART DESCRIPTION

#### PART #

GFCI Receptacle, 15 Amp, Color: Ivory

5L269C

Receptacle Box, Aluminum

5L98A

### HEATER

#### PART DESCRIPTION

#### PART #

Heater, Strip/Panel Mount with Thermostat – UL Listed 120 Volt 500 Watt  
(OBSOLETE P/N 4L364 replaced with P/N 4L364A)

4L364A

Heater, Auxiliary, with Fan, 120 Volt 1320/1650 Watt

4L84

Fan Motor for 4L84 Heater

OBSOLETE

Temperature Transmitter

5L350AA

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 10

## ELECTRICAL COMPONENTS (CONTINUED)

### LIGHTNING PROTECTION

PART DESCRIPTION	PART #
Surge Capacitor	4L368
Lightning Arrestor	4L369

### PHASE MONITOR RELAYS

PART DESCRIPTION	PART #
Phase Monitor, Voltage: 190 to 270	4L336A
Phase Monitor, Voltage: 430 to 480	4L336B

### POWER SUPPLY – 24 VOLT

*Powers all 24 volt panel components*

PART DESCRIPTION	PART #
Power Supply, 24 VDC (2.3 Amp rating)	4L452C

### PRESSURE TRANSDUCERS/SENSORS, SUBMERSIBLE

(Submersible Pressure Transducer hangs down from the pump station and into the wet well, in addition to the float switches used for back-up. Both are used for wet well level sensing.)

PART DESCRIPTION	PART #
0-15 PSI, Submersible Pressure Transducer – 25' Cord (old style)	See
(Old PN: 4L563B-Now 4L563J + reprogrammed E-PROM through Retrofit)	Retrofit
0-7.5 PSI, Submersible Pressure Transducer – 30' Cord (Replaces 4L563A) (CURRENT STYLE) (Replaces 4L563C).	4L563J

### PROTRONIX® CONTROLLER

PART DESCRIPTION	PART #
PROTRONIX® II Input/Output Module (8 In/8 Out) Expansion Card	4L536C-2
PROTRONIX® II Controller - 4L452C-1 (SOLD THRU RETROFIT ONLY)	Call Retrofits

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 11

## ELECTRICAL COMPONENTS (CONTINUED)

### RELAYS

PART DESCRIPTION	PART #
Relay, Vacuum Pump Contactor	4L862A
Relay, Time Delay (for Pump Failure, Prime Failure, Time Delay)	4L304J
Relay, 24 VDC, Din Rail Mounted (Double Pole, Double Throw)	4L571D
Relay, 24 VDC, Din Rail, SPST	4L571A
<b>SONIC START®</b> Operating Module	4L264
<b>WAVESTART®</b> Operating Module	4L264E

### RESISTOR

PART DESCRIPTION	PART #
250 OHM Resistor Wire	4L587A

### SOLENOID VALVE, 2-WAY LARGE PORT

PART DESCRIPTION	PART #
2-Way Solenoid Valve (5/16" orifice) Cannot be used with <b>SONIC START® STREAMLINE™</b>	1L545B conduit connection mounted through panel & backpan
2-Way Solenoid Valve Assembly for the <b>FORMULA X®</b>	87B351
<b>SONIC START® STREAMLINE™</b> and <b>WAVESTART®</b> Solenoid Valve/ Dome Assembly	87B728

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 12

## ELECTRICAL COMPONENTS (CONTINUED)

### SWITCHES

PART DESCRIPTION	PART #
Switch, 3-POS Operator Selector, Spring Return Left, HOA (Hand-Off-Auto)	4L13C
Switch, Limit for Intrusion Alarm	5L241
Actuator, for use with 5L241	5L241A
Switch, 2-POS Operator Selector, Keyed	4L366A
Switch (Alarm), 2-POS Operator Selector, Maintained	4L71
Switch, 3-POS Operator Selector, Spring Return Left, HOA	4L13C
Switch, Push Button	4L561A
Float Switch (Normally Open <b>Blue</b> ), 30 ft. cord	4L291A
Float Switch (Normally Closed <b>Red</b> ), 30 ft. cord	4L291B
Float Switch (Normally Open <b>Blue</b> ), 45 ft. cord	4L291C
Mercury-Free (Normally Open, Normally Closed) 40ft cord	4L291F

### TEMPERATURE TRANSMITTER

PART DESCRIPTION	PART #
Temperature Transmitter	5L350AA

### TRANSFORMER

#### DESCRIPTION

#### PART #

2 KVA, 240/480 TO 120/240	4L402A
3 KVA, 240/480 TO 120/240	4L402B
3 KVA, 208 TO 120/240	4L402D
5 KVA, 240/480 TO 120/240	4L402E
5 KVA, 208 TO 120/240	4L402EA

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 13

## ELECTRICAL COMPONENTS (CONTINUED)

### IEC RATED STARTERS – 4L915 MOTOR CIRCUIT PROTECTORS – 4L531, 4L532

MOTOR HORSEPOWER	208 VOLTS		230 VOLTS		460 VOLTS	
	STARTER PART #	CIRCUIT PROTECTOR PART #	STARTER PART #	CIRCUIT PROTECTOR PART #	STARTER PART #	CIRCUIT PROTECTOR PART #
1½	4L915D	4L531F	4L915D	4L531F	4L915C	4L531E
2	4L915Q	4L531F	4L915D	4L531F	4L915C	4L531E
3	4L915Q	4L531F	4L915Q	4L531F	4L915D	4L531E
5	4L915F	4L531G	4L915F	4L531G	4L915Q	4L531F
7½	4L915G	4L531A	4L915G	4L531G	4L915E	4L531F
10	4L915B	4L531A	4L915H	4L531A	4L915F	4L531G
15	4L915J	4L531B	4L915J	4L531B	4L915G	4L531G
20	4L915K	4L531C	4L915J	4L531C	4L915H	4L531A
25	4L915L	4L531D	4L915K	4L531C	4L915H	4L531A
30	4L915M	4L532G	4L915L	4L532A	4L915J	4L531A
40	4L915R	4L532H	4L915N	4L532B	4L915J	4L531B
50			4L915R	4L532H	4L915K	4L531C
60					4L915L	4L531D
75					4L915M	4L532B
100					4L915R	4L532B

**SPECIAL NOTE:** Starter Motor Circuit Protector Sizing has changed slightly over the years. Consult Factory's BOM for Direct Replacement and to check dimensions.

**PARTS ORDERING NOTE:** If the customer is replacing older starters with new starters (new part numbers listed above), they will also need to purchase new auxiliary contacts.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 14

## ELECTRICAL COMPONENTS (CONTINUED)

### NEMA RATED STARTERS – 4L514 MOTOR CIRCUIT PROTECTORS – 4L531, 4L532

MOTOR HORSEPOWER	208 VOLTS		230 VOLTS		460 VOLTS	
	STARTER PART #	BREAKER PART #	STARTER PART #	BREAKER PART #	STARTER PART #	BREAKER PART #
1½	4L930B	4L531F	4L930B	4L531F	4L930B	4L531E
2	4L930B	4L531F	4L930B	4L531F	4L930B	4L531E
3	4L930B	4L531F	4L930B	4L531F	4L930B	4L531E
5	4L930E	4L531G	4L930E	4L531G	4L930B	4L531F
7½	4L930F	4L531A	4L930F	4L531G	4L930E	4L531F
10	4L930G	4L531A	4L930G	4L531A	4L930E	4L531G
15	4L930H	4L532F	4L930H	4L531B	4L930G	4L531G
20	4L930H	4L532E	4L930H	4L532F	4L930G	4L531A
25	4L930H	4L532A	4L930H	4L532E	4L930G	4L531A
30	4L930J	4L532G	4L930J	4L532A	4L930H	4L531A
40	4L930J	4L532H	4L930J	4L532B	4L930H	4L532A
50			4L930J	4L532H	4L930J	4L532B
60					4L930J	4L532B
75					4L930J	4L532B
100					4L930J	4L532H

**NOTE:** Use NEMA rated starters if dimensions are checked and will fit in panel.

**PARTS ORDERING NOTE:** If the customer is replacing older starters with new starters (new part numbers listed above), they will also need to purchase new auxiliary contacts.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 15

## ELECTRICAL COMPONENTS (CONTINUED)

### NEMA RATED STARTERS – 4L421

Motor Horsepower	208 Volts	230 Volts	460 Volts
	Part Numbers	Parts Numbers	Parts Numbers
¾ & 1	4L421A	4L421A	4L421A
1½	4L421A	4L421A	4L421A
2	4L421A	4L421A	4L421A
3	4L421A	4L421A	4L421A
5	4L421B	4L421B	4L421B
7½	4L421B	4L421B	4L421B
10	4L421C	4L421C	4L421B
15	4L421D	4L421C	4L421C
20	4L421D	4L421D	4L421C
25	4L421D	4L421D	4L421C
30	4L421E	4L421D	4L421D
40	4L421E	4L421E	4L421D
50	4L421F	4L421E	4L421D
60	4L421F	4L421F	4L421E
75	4L421F	4L421F	4L421E
100	Special Order	4L421F	4L421E

**PARTS ORDERING NOTE:** If the customer is replacing older starters with new starters (new part numbers listed above), they will also need to purchase new overload coils and auxiliary contacts.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 16

## ELECTRICAL COMPONENTS (CONTINUED)

### OVERLOAD COILS – I.E.C. & NEMA STARTERS

Motor Horsepower	208 Volts	230 Volts	460 Volts
	Part Number	Part Number	Part Number
¾	4L413H	4L416G	4L413E
1	4L413H	4L413H	4L413F
1½	4L413J	4L413J	4L413G
2	4L413K	4L413K	4L413H
3	4L413L	4L413L	4L413J
5	4L413M	4L413M	4L413K
7½	4L413N	4L413N	4L413L
10	4L413P	4L413P	4L413M
15	4L413R	4L413Q	4L413N
20	4L413T	4L413X	4L413P
25	4L413Y	4L413Y	4L413Q
30	4L413Z	4L413Y	4L413W
40	4L413AA	4L413Z	4L413X
50		4L413AA	4L413Y
60			4L413Y
75			4L413Z
100			4L413AA

**PARTS ORDERING NOTE:** If the customer is replacing older starters with new starters (new part numbers listed above), they will also need to purchase new overload coils.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 17

## ELECTRICAL COMPONENTS (CONTINUED)

### THREE PHASE MOTOR CIRCUIT BREAKERS –

Use when increasing or decreasing horsepower.

Motor HP	208 Volts	230 Volts	460 Volts
	Part Numbers	Parts Numbers	Parts Numbers
1½	4L531F	4L531F	4L531E
2	4L531F	4L531F	4L531E
3	4L531F	4L531F	4L531E
5	4L531G	4L531G	4L531F
7½	4L531A	4L531A	4L531G
10	4L531A	4L531A	4L531G
15	4L531B	4L531B	4L531G
20	4L531C	4L531C	4L531A
25	4L164P	4L531C	4L531B
30	4L164P	4L164P	4L531C
40	4L431CW	4L164P	4L531C
50	-	-	4L164P
60	-	-	4L164P
	-	-	-

**REQUIREMENTS FOR 208 VOLTS:** 40 HP OR HIGHER SELECT 480 VOLT OPTIONS AS NOTED.

**REQUIREMENTS FOR 230 VOLTS:** 50 HP OR HIGHER SELECT 480 VOLT OPTIONS AS NOTED.

### SINGLE PHASE MOTOR CIRCUIT BREAKERS –

Use when increasing or decreasing horsepower.

230 Volts	
Motor HP	Parts Numbers
¼	4L218B
1/3	4L218B
½	4L218B
¾	4L218B
1	4L218B
1½	4L218C
2	4L218D
3	4L218F
5	4L218H

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 18

## ELECTRICAL COMPONENTS (*CONTINUED*)

### MOTORS – VERTICAL “P”

---

BASE PUMP MOTORS, TEFC, 3/60/230-460 VOLT

STANDARD SEAL

---

Call factory to determine correct motor requirements station serial number required.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 19

## ELECTRICAL COMPONENTS (CONTINUED)

### BREAKERS – “QUICKLAG C” TYPE, SINGLE POLE, 5000 AMPERE INTERRUPTING CAPACITY, 120/240 VAC (TYPICALLY CONTROLS CIRCUIT BREAKER)

PART DESCRIPTION	PART #
10, Continuous Amp Rating	4L82B
15, Continuous Amp Rating	4L82C
20, Continuous Amp Rating	4L82D
30, Continuous Amp Rating	4L82F
35, Continuous Amp Rating	4L82G
40, Continuous Amp Rating	4L82H
50, Continuous Amp Rating	4L82J
Handle Tie (California)	4L82P

### BREAKERS – “QUICKLAG C” TYPE, AB DE-LON, 2 POLE, 10-100 AMPERES, 240 VAC (TYPICALLY TRANSFORMER CIRCUIT BREAKER OR SINGLE PHASE PUMP MOTORS)

PART DESCRIPTION	PART #
10, Continuous Amp Rating	4L218A
15, Continuous Amp Rating	4L218B
20, Continuous Amp Rating	4L218C
25, Continuous Amp Rating	4L218D
30, Continuous Amp Rating	4L218E
35, Continuous Amp Rating	4L218F
40, Continuous Amp Rating	4L218G
50, Continuous Amp Rating	4L218H
60, Continuous Amp Rating	4L218J
70, Continuous Amp Rating	4L218K
90, Continuous Amp Rating	4L218L
100, Continuous Amp Rating	4L218M
Breaker Handle Lock – “Quicklag C” Type	4L403

**PARTS ORDERING NOTE:** Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 20

## ELECTRICAL COMPONENTS (*CONTINUED*)

**BREAKERS – “QUICKLAG C” TYPE, AB DE-LON, 2 POLE, 10-100  
AMPERES, 480 VAC**

**(TYPICALLY TRANSFORMER CIRCUIT BREAKER OR SINGLE PHASE  
PUMP MOTORS)**

PART DESCRIPTION	PART #
15, Continuous Amp Rating	4L258BA
20, Continuous Amp Rating	4L258BB
25, Continuous Amp Rating	4L258BC
30, Continuous Amp Rating	4L258BD
35, Continuous Amp Rating	4L258BE
40, Continuous Amp Rating	4L258BF
45, Continuous Amp Rating	4L258BP
50, Continuous Amp Rating	4L258BG
60, Continuous Amp Rating	4L258BH
70, Continuous Amp Rating	4L258BJ
80, Continuous Amp Rating	4L258BQ
90, Continuous Amp Rating	4L258BK
100, Continuous Amp Rating	4L258BL
Breaker Handle Lock – “Quicklag C” Type	4L403

**PARTS ORDERING NOTE:** Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 21

## ELECTRICAL COMPONENTS (CONTINUED)

### BREAKERS – “QUICKLAG C” TYPE, AB DE-LON, 3 POLE, 10-100 AMPERES, 240 VAC

(TYPICALLY USED WITH 3 PHASE PUMP MOTORS 240 AND BELOW)

#### PART DESCRIPTION

#### PART #

10, Continuous Amp Rating *	4L202A **
15, Continuous Amp Rating	4L202B
20, Continuous Amp Rating	4L202C
25, Continuous Amp Rating	4L202D
30, Continuous Amp Rating	4L202E
35, Continuous Amp Rating	4L202F
40, Continuous Amp Rating	4L202G
45, Continuous Amp Rating	4L202P
50, Continuous Amp Rating	4L202H
55, Continuous Amp Rating	4L202J
60, Continuous Amp Rating	4L202K
70, Continuous Amp Rating	4L202L
80, Continuous Amp Rating	4L202Q
90, Continuous Amp Rating	4L202M
100, Continuous Amp Rating	4L202N
Breaker Handle Lock – “Quicklag C” Type	4L403

**PARTS ORDERING NOTE:** Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

### MOUNTING STRAP FOR BREAKERS – “QUICKLAG C” TYPE

#### PART DESCRIPTION

#### PART #

Mounting Strap	4L83
----------------	------

\* Not UL Listed

\*\* Low Usage Item

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 22

## ELECTRICAL COMPONENTS (CONTINUED)

**BREAKERS – THERMAL MAGNETIC TYPE EHD, 1/2/3 POLE, 10-100 AMPS  
(15,000 AMPS INTERRUPTING CAPACITY)  
(TYPICALLY USED WITH 3 PHASE PUMP MOTORS 480 VOLT)**

AMP RATING @ 40°F (CONT.)	1-POLE 277 VAC (MAX.)	2-POLE 277 VAC (MAX.)	3-POLE 480 VAC (MAX.)
10 *	4L258AN **	4L258BN **	4L258CN **
15	4L258AA	4L258BA	4L258CA
20	4L258AB	4L258BB	4L258CB
25	4L258AC	4L258BC	4L258CC
30	4L258AD	4L258BD	4L258CD
35	4L258AE	4L258BE	4L258CE
40	4L258AF	4L258BF	4L258CF
45	4L258AP	4L258BP	4L258CP
50	4L258AG	4L258BG	4L258CG
60	4L258AH	4L258BH	4L258CH
70	4L258AJ	4L258BJ **	4L258CJ
80	4L258AQ	4L258BQ	4L258CQ
90	4L258AK	4L258BK	4L258CK
100	4L258AL	4L258BL	4L258CL
100 NA	4L258AM	4L258BM	4L258CM
Breaker Handle Lock – "EHD" Type			4L404

**PARTS ORDERING NOTE:** Each time a Breaker is ordered as a part or with a retrofit, a Breaker Handle Lock is required.

## BREAKERS – MCP MOTOR CIRCUIT PROTECTOR, 3-POLE

TRIP RANGE AMPS	CONTINUOUS AMP RATING	PART #
100 – 300	30	4L164D
160 – 480	50	4L164E
275 – 1000	100	4L164F
450 – 1550	150	4L164G
Transformer	Breaker	4L218B

\* Not UL Listed

\*\* Low Usage Item

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 23

## MECHANICAL, PIPING, & PARTS

### PUMP PARTS

**VERIFY ALL CASTED PARTS WITH FACTORY**

	4B2B*1	4B2D*1
	<b>Pump</b>	<b>Pump</b>
Shaft Diameter	1 7/8"	1 7/8"
Mechanical Seal Kit	H87A28	H87A28
Impeller, CW (Clockwise)	60B265A	60B269A
Impeller, CCW (Counter-Clockwise)	60B265B	60B269B
Maximum Diameter	10 1/8"	10 1/8"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165A-304	60B165A-304
Suction Piping		
Integral Volute & Front Head, CCW	87B286A-304 – 4" Suc. Piping 87B287A-304 – 6" Suc. Piping	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 - 4" Suc. Piping 87B287B-304 – 6" Suc. Piping	87B286B-304– 4" Suc. Piping 87B287B-304– 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping	87B239-304– 4" Suc. Piping 87B241-304 – 6" Suc. Piping
Flange Gasket	11L1A – 4" Suc. Piping 11L1C – 6" Suc. Piping	11L1A – 4" Suc. Piping 11L1C – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping 6L178F– 6" Suc. Piping	6L178B – 4" Suc. Piping 6L178F– 6" Suc. Piping
Discharge Pipe – 4"	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping 2L7B-304 – 6" piping	2L7A-304 – 4" piping 2L7B-304 – 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only	2L28AH-304	2L28AH-304
4" piping with 5'/6' diameter Wet Well doesn't use 6" piping with 5'/6' diameter Wet Well	2L86B009J-304	2L86B009J-304
Plug Valve	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve) 4" standard elbow, 6" reducing elbow	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6" 2L153S 87A255
Check Valve Assembly, LH – 4"	2L153S 87A255 (Flange Gasket)	(Flange Gasket)
Check Valve Assembly, LH – 6"	2L153Q-304 87A224 (Flange Gasket)	2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH – 4"	2L153T 87A255 (Flange Gasket)	2L153T 87A255 (Flange Gasket)
Check Valve Assembly, RH – 6"	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A26 (1/32")	60A26 (1/32")
Impeller Bolt	60A12	60A12
Impeller Washer	60A20	60A20

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 24

## MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS	4B3B*1	4C2B*1
<b>VERIFY ALL CASTED PARTS WITH FACTORY</b>		
Shaft Diameter	17/8"	2 1/8"
Mechanical Seal Kit	H87A28	H87A97
Impeller, CW (Clockwise)	60B272A	60B265C
Impeller, CCW (Counter-Clockwise)	60B272B	60B265D
Maximum Diameter	12"	10-1/8"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165D-304	60B165B-304
Suction Piping		
Integral Volute & Front Head, CCW	87D310A-304 – 4" Suc. Piping 87D311A-304 – 4" Suc. Piping	87B286A-304 – 4" Suc. Piping 87B287A-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87D310B-304 – 4" Suc. Piping 87D311B-304 – 4" Suc. Piping	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping
Flange Gasket	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping
Discharge Pipe	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping 2L7B-304 – 6" piping	2L7A-304 – 4" piping 2L7B-304 – 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only 4" piping with 5/6' diameter Wet Well doesn't use 6" piping with 5/6' diameter Wet Well	2L28AJ-304 2L86B014-304	2L28AH-304 2L86B009J-304
Plug Valve	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve) 4" standard elbow, 6" reducing elbow	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"
Check Valve Assembly, LH – 4"	2L153S	2L153S
Check Valve Assembly, LH – 6"	87A255 (Flange Gasket) 2L153Q-304	87A255 (Flange Gasket) 2L153Q-304
Check Valve Assembly, RH – 4"	87A224 (Flange Gasket)	87A224 (Flange Gasket)
Check Valve Assembly, RH – 6"	2L153T	2L153T
Volute Gasket (1/64 & 1/16 thickness available)	87A255 (Flange Gasket) 2L153R-304	87A255 (Flange Gasket) 2L153R-304
Impeller Bolt	87A224 (Flange Gasket)	87A224 (Flange Gasket)
Impeller Washer	60A28 (1/32")	60A26 (1/32")
	60A12	60A12
	60A20	60A20

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 25

## MECHANICAL, PIPING, & PARTS (CONTINUED)

### PUMP PARTS

**VERIFY ALL CASTED PARTS WITH FACTORY**

	<b>4C2D*1</b> <b>Pump</b>
Shaft Diameter	2 1/8"
Mechanical Seal Kit	H87A97
Impeller, CW (Clockwise)	60B269C
Impeller, CCW (Counter-Clockwise)	60B269D
Maximum Diameter	10-1/8"
Suction Side - Diameter Eye	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165B-304
Suction Piping	
Integral Volute & Front Head, CCW	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping
Flange Gasket	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping
Discharge Pipe – 4"	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping 2L7B-304 – 6" piping
Tee	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only 4" piping with 5'/6' diameter Wet Well doesn't use 6" piping with 5'/6' diameter Wet Well	2L28AH-304 2L86B009J-304
Plug Valve	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve) 4" standard elbow, 6" reducing elbow	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"
Check Valve Assembly, LH – 4" Check Valve Assembly, LH – 6"	2L153S 87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH – 4" Check Valve Assembly, RH – 6"	2L153T 87A255 (Flange Gasket) 2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A26 (1/32")
Impeller Bolt	60A12
Impeller Washer	60A20

**PARTS ORDERING NOTE:** Remind customer that gaskets may be needed when ordering casted parts

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 26

## MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS <i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	4C3B*1 Pump	4D3B*1 Pump
Shaft Diameter	2 $\frac{1}{8}$ "	3"
Mechanical Seal Kit	H87A97	H87A534
Impeller, CW (Clockwise)	60B272C	60B272E
Impeller, CCW (Counter-Clockwise)	60B272D	60B272F
Maximum Diameter	12"	12"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165E-304	60B165M-304
Suction Piping		
Integral Volute & Front Head, CCW	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 - 6" Suc. Piping	87B239-304 - 4" Suc. Piping 87B241-304 - 6" Suc. Piping
Flange Gasket	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping
Discharge Pipe	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping 2L7B-304 – 6" piping	2L7A-304 – 4" piping 2L7B-304 – 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only	2L28AJ-304	2L28AJ-304
4" piping with 5'/6' diameter Wet Well doesn't use 6" piping with 5'/6' diameter Wet Well	2L86B014-304	2L86B014-304
Plug Valve	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve)	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"	87B242-304 & 87B243-304 – 4" 87B244-304 & 87B245-304 – 6"
Check Valve Assembly, LH – 4"	2L153S	2L153S
Check Valve Assembly, LH – 6"	87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)	87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH – 4"	2L153T	2L153T
Check Valve Assembly, RH – 6"	87A255 (Flange Gasket) 2L153R-304 87A224 (Flange Gasket)	87A255 (Flange Gasket) 2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A28 (1/32")	60A28 (1/32")
Impeller Bolt	60A12	60A87
Impeller Washer	60A20	60A86

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 27

## MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS	4B2X*1	4C2X*1
<b>VERIFY ALL CASTED PARTS WITH FACTORY</b>		
Shaft Diameter	1 7/8"	2 1/8"
Mechanical Seal Kit	H87A28	H87A97
X-PELLER®, CW (Clockwise)	60B252A	60B252C*
X-PELLER®, CCW (Counter-Clockwise)	60B252B	60B252D *
Maximum Diameter	10-1/8"	10-1/8"
Suction Side - Diameter Eye	4"	4"
Motor Adapter-Also sell S/N NAMEPLATE	60B165A-304	60B165B-304
Suction Piping		
Integral Volute & Front Head, CCW	87B286A-304 – 4" Suc. Piping 87B287A-304 – 6" Suc. Piping	87B286A-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Integral Volute & Front Head, CW	87B286B-304 - 4" Suc. Piping 87B287B-304 – 6" Suc. Piping	87B286B-304 – 4" Suc. Piping 87B287B-304 – 6" Suc. Piping
Mounting Adapter	87B239-304 - 4" Suc. Piping 87B241-304 – 6" Suc. Piping	87B239-304- 4" Suc. Piping 87B241-304 – 6" Suc. Piping
Flange Gasket	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping	11L1AA – 4" Suc. Piping 11L1CA – 6" Suc. Piping
Socket Head Capscrew	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping	6L178B – 4" Suc. Piping 6L178F – 6" Suc. Piping
Discharge Pipe	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping	28A549BE-304 – 4" piping 28A550BX-304 – 6" piping
Elbow (Between Discharge Pipe & Tee)	2L7A-304 – 4" piping 2L7B-304 – 6" piping	2L7A-304 – 4" piping 2L7B-304 – 6" piping
Tee (Required only on 4" piping)	2L12A-304	2L12A-304
Flange Filler – Use on 4' diameter Wet Well Only	2L28AH-304	2L28AH-304
4" piping with 5'/6' diameter Wet Well doesn't use 6" piping with 5'/6' diameter Wet Well	2L86B009J-304	2L86B009J-304
Plug Valve	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd	2L104A-304 – 4" piping 2 req'd 2L148M-304 – 6" piping 1 req'd
Elbow (Between Plug Valve & Check Valve)	87B242-304 & 87B243-304 – 4"	87B242-304 & 87B243-304 – 4"
4" standard elbow, 6" reducing elbow	87B244-304 & 87B245-304 – 6"	87B244-304 & 87B245-304 – 6"
Check Valve Assembly, LH – 4"	2L153S	2L153S
Check Valve Assembly, LH – 6"	87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)	87A255 (Flange Gasket) 2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH – 4"	87A255 (Flange Gasket)	87A255 (Flange Gasket)
Check Valve Assembly, RH – 6"	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A26 (1/32")	60A26 (1/32")
Impeller Bolts	60A12	60A12
Impeller Washer	60A20	60A20

**PARTS ORDERING NOTE:** Remind customer that gaskets may be needed when ordering casted parts

© 2006 -2021 Smith & Loveless, Inc.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 28

## MECHANICAL, PIPING, & PARTS (CONTINUED)

PUMP PARTS <i>VERIFY ALL CASTED PARTS WITH FACTORY</i>	6B3B*1 Pump	6C3B*1 Pump	6D3B*1 Pump
Shaft Diameter	1 7/8"	2 1/8"	3"
Mechanical Seal Kit	H87A28	H87A97	H87A534
Impeller, CW (Clockwise)	60B273A	60B273C	60B273E
Impeller, CCW (Counter-Clockwise)	60B273B	60B273D	60B273F
Maximum Diameter	12"	12"	12"
Suction Side - Diameter Eye	5 1/8"	5 1/8"	5 1/8"
Motor Adapter-Also sell S/N NAMEPLATE	60B165D-304	60B165E-304	60B165M-304
Suction Piping			
Volute	60D35-304	60D35-304	60D35-304
Front Head	60C88-304	60C88-304	60C88-304
Mounting Adapter	87B241-304	87B241-304	87B241-304
Flange Gasket	11L1CA	11L1CA	11L1CA
Socket Head Capscrew	6L17BF	6L17BF	6L17BF
Front Head	60C88-304	60C88-304	60C88-304
Pump Stand	None	None	None
Discharge Pipe 8" needs 2L28013-304 + 2L201B	2L28013-304 – 6"	2L28013-304 – 6"	2L28013-304 – 6"
Elbow (Between Discharge Pipe & Tee)	2L7B	2L7B	2L7B
Tee	None	None	None
Flange Filler	2L86BO12D-304	2L86BO12D-304	2L86BO12D-304
Plug Valve	2L148M-304	2L148M-304	2L148M-304
Elbow (Between Plug Valve & Check Valve)	87B246-304 & 87B247-304	87B246-304 & 87B247-304	87B246-304 & 87B247-304
Check Valve Assembly, LH – 6"	2L153Q-304 87A224 (Flange Gasket)	2L153Q-304 87A224 (Flange Gasket)	2L153Q-304 87A224 (Flange Gasket)
Check Valve Assembly, RH – 6"	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)	2L153R-304 87A224 (Flange Gasket)
Volute Gasket (1/64 & 1/16 thickness available)	60A28 (1/32")	60A28 (1/32")	60A28 (1/32")
Impeller Bolt	60A12	60A12	60A87
Impeller Washer	60A20	60A20	60A86

**PARTS ORDERING NOTE:** Remind customer that gaskets may be needed when ordering casted parts

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 29

## MECHANICAL, PIPING, & PARTS (CONTINUED)

### MECHANICAL SEALS

SEAL & SPARE PARTS	B-SHAFT	C-SHAFT	D-SHAFT
	1 7/8"	2 1/8"	3"
<b>Seal Kit, Mechanical Seal</b>	H87A28	H87A97	H87A534
Bronze Seal Housing	87B2	87B19 ***	87B73 ***
<b>Seal Housing – Flat Gasket **</b>	60A11	60A17	60A84
<b>Seal Housing - Quad Ring **</b>	60A110	60A111	60A146
Ceramic Rotating Wear Ring	60A32 *	60A33 *	60A85 *
Carbon Stationary Wear Ring	60A36 *	60A37 *	60A52 *
Rotating O-Ring	60A39 *	60A41 *	60A53 *
Stationary Quad Ring	60A38 *	60A40 *	60A54 *
Spring	60A30 *	60A31 *	60A55 *
<b>Impeller Bolt</b>	60A12	60A12	60A87
<b>Impeller Washer</b>	60A20	60A20	60A86
<b>Volute Gasket</b>	See Volute Gasket Table On Page 31		

\* Parts contained in H87A28, H87A97, or H87A182 Mechanical Seal Kits

**PARTS ORDERING NOTE:** Each time the impeller bolt is removed (required for seal replacement), Smith & Loveless recommends installation of a new impeller bolt that has the embedded Nylock.

**PARTS ORDERING NOTE** Each time a new seal, ceramic, carbon or spring is installed, a volute gasket, seal housing gasket or quad ring, and impeller bolt are recommended.

**\*\* PARTS TIP:** Seal Housing - Flat Gasket vs. Quad Ring: The older seal housing has a flat surface and uses the flat gasket for both the single and double mechanical seals. The newer seal housing has a groove and it can use either the flat gasket or the quad ring.

**\*\*\* SEAL HOUSING:** Call factory for different seal housings for 4-frame pumps.(4B4B, 6C4V)

**\*\*\*\*BOLDED PARTS:** Always quote all bolded parts when quoting a mechanical seal kit.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 30

## MECHANICAL, PIPING, & PARTS (CONTINUED)

### **DOUBLE BALANCED (FOR OVER 200' TDH\*\*\*\*) MECHANICAL SEALS**

#### **SEAL & SPARE PARTS**

**(HIGH HEAD SEALS – For Over 200' TDH\*\*\*\* or  
Series P.S.)**

	C-SHAFT 2-1/8"	D-SHAFT 3"
<b>Seal Kit, Mechanical Seal – Double Balanced (DOES NOT INCLUDE BALANCE SLEEVE)</b>	H60A156	H87A534
Complete Assembly including Bronze Seal Housing & Mechanical Seal (Parts include Upper Housing thru Lower Housing) <i>(Order one extra Seal Housing Quad Ring)</i>	87C425	87C427
Bronze Seal Housing, Upper	87C424	87C428
Bronze Seal Housing, Lower	60C95	60C97
<b>Seal Housing Gasket - Flat ***</b>	60A17	60A84
<b>Seal Housing Gasket - Quad Ring ***</b>	60A111	60A112
Ceramic Rotating Wear Ring (requires 2)	60A155 *	60A85 *
Carbon Stationary Wear Ring (requires 2)	60A153 *	60A136 *
Stationary Quad Ring (requires 2)	11L47E *	60A54 *
Spring	60A154 *	60A135 *
O-Ring-Balance Sleeve, Inner (D-Shaft – new style sleeve 60B277/B requires 2, old style sleeve 60B277/A requires 1)	11L207C *	11L207A *
O-Ring Balance Sleeve, Outer (Both old & new require two out O-Rings)	11L207D *	11L207B *
Balance Sleeve	60B259**	60B277**
<b>Impeller Bolts</b>	60A12	60A87
<b>Impeller Washer</b>	60A20	60A86
<b>Volute Gaskets</b>	See the Volute Gasket Table	

**BOLDED PARTS:** Always quote all bolded parts when quoting a mechanical seal kit.

\* Parts contained in H60A156 or H60A137 Double Balanced Mechanical Seal Kits

\*\* **PARTS ORDERING NOTE:** Each time the balance sleeves are replaced, new Balance Sleeve O-Rings are recommended.

**PARTS ORDERING NOTE:** Each time the impeller bolt is removed (required for seal replacement), Smith & Loveless recommends installation of a new impeller bolt that has the embedded Nylock.

**PARTS ORDERING NOTE:** Each time a new seal, ceramic, carbon or spring is installed, a volute gasket, seal housing gasket or quad ring, and impeller bolt are recommended.

\*\*\* **PARTS TIP:** Seal Housing – Flat Gasket vs. Quad Ring: The older seal housing has a flat surface and uses the flat gasket for both the single and double mechanical seals. The newer seal housing has a groove and it can use either the flat gasket or the quad ring.

\*\*\*\* **NOTE:** Series 4 Pump C&D Shaft WWMPS-See Factory. High Head Seals on Second Stage Pumps may be required For Over 200'TDH. Add Pump 1 & Pump 2 TDH together to determine if more than 200'TDH. See Factory.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 31

## MECHANICAL, PIPING, & PARTS (CONTINUED)

### PUMP IMPELLERS & PUMP X-PELLERS® - VACUUM PRIMED

PUMP MODEL	MOTOR RPM	IMPELLER CW PART #	IMPELLER CCW PART #	ADDITIONAL PARTS 1 SET PER IMPELLER PART#
4B2B*1	-	60B265A	60B265B	60A12, 60A20, 60A26
TURBO 4B2C	-	87D103	87D104	60A12, 60A20, 60A26
4B2D*1	-	60B269A	60B269B	60A12, 60A20, 60A26
4B2X*1	-	60B252A	60B252B	60A12, 60A20, 60A26
4B3B*1	-	60B272A	60B272B	60A12, 60A20, 60A28
4C2B*1	-	60B265C	60B272B	60A12, 60A20, 60A26
4C2D*1	-	60B269C	60B269D	60A12, 60A20, 60A26
4C2X*1	-	60B252C	60B252D	60A12, 60A20, 60A26
4C3B*1	-	60B272C	60B272D	60A12, 60A20, 60A28
4D3B*1	-	60B272E	60B272F	60A87, 60A86, 60A28
4D4B	-	60D259	60D258	60A87, 60A86, 60A106B
6B3B*1 (& SERIES)	-	60B273A	60B273B	60A12, 60A20, 60A28
6B3X	-	60B204	60B209	60A12, 60A20, 60A28
6C3B*1 (& SERIES)	-	60B273C	60B273D	60A12, 60A20, 60A28
6C3X	-	60B217	60B2118	60A12, 60A20, 60A28
6D3B*1 (& SERIES)	-	60B273E	60B273F	60A87, 60A86, 60A28
6D3X	-	60B219	60B220	60A87, 60A86, 60A28
8C4D	-	60D178	60D179	60A12, 60A20, 60A106B
8D4D	-	60D150	60D151	60A87, 60A86, 60A106B

GASKETS, VOLUTE PUMP SIZE	STANDARD GASKET PART #	OTHER VOLUTE GASKETS PART # 1/16" THICKNESS
4B2B*1, 4B2C, 4B2D, 4C2B, 4C2D, 4B2X*1, 4C2X	60A26 (1/32")	60A27 (1/16")
4B3B, 4C3B, 4D3B, 6B3B, 6C3B, 6D3B	60A28 (1/32")	60A29 (1/16")

**PARTS ORDERING NOTE:** New volute gasket is required each time the rotating assembly (motor, impeller, mechanical seals, &/or volute) is disassembled.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 32

## OTHER PARTS

### ALARMS

PART DESCRIPTION	PART #
Horn, 120 VAC, 60 cycle	4L73A
Horn, 12 VDC.	4L73B
Horn, Weatherproof Box	4L73D

### RED ALARM LIGHT ASSEMBLY:

Light, Red 12 VDC	28B580A
Lamp, 12 VDC, 50 W for 28B580A Light	4L120
Light, Red 120 VAC	28B580B
Lamp, 120 VAC, 50 W for 28B580B Light	4L95A
Light Fixture Body	5L76*
Light Fixture Adapter	5L77*
Red Globe for 5L77	5L78B*
Globe Guard for 5L77	5L79 *
Trickle Charger (OLD STYLE)	4L222

\* PARTS ORDERING NOTE: Must identify as either Appleton or Killark

\*\*Consult the factory.

### BLOWER - VENTILATION

PART DESCRIPTION	PART #
Blower – 265 CFM	7L195
Electrical Cord – 15' - Coiled	4L379B
Cord Connector	5L15A
Air Discharge Seal (seals blower to hood)	87A86
Blower & Cord Assembly (includes blower, cord connector and 15' coiled cord)	87A414B
Air Discharge Seal (seals blower to hood)	87A86
Louver, Adjustable 6 x 6	11L138A
Seal for Louver (Placed between louver & fiberglass)	87A86

### FORM-A-GASKET

PART DESCRIPTION	PART #
Form-A-Gasket, 1.5 oz.	12L90A

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 33

## OTHER PARTS (CONTINUED)

### GASKETS

#### PART DESCRIPTION

#### PART #

4" Flange Gasket (check valves & suction/discharge piping)	11L1A
6" Flange Gasket (check valves & suction/discharge piping)	11L1C
Volute/Base Gasket	60A108
	B Shaft: 60A110
Seal Housing Gasket - Quad Ring *	C Shaft: 60A111
	D Shaft: 60A146
Hood Gasket, 64" X 156"	10L122AD
Hood Gasket, 72" X 172"	10L122AD
Baseplate Gasket, 64" X 59"	10L122AB
Baseplate Gasket, 72" X 67"	10L122AB

\* **PARTS TIP:** Seal Housing Gasket - Flat vs. Quad Ring. The seal housing has a groove and can use either gasket

\* **3-1/2" diameter dial (Customer must verify fit. If smaller dial is needed, contact factory)**  
**PARTS ORDERING TIP: If no gauge is currently in use, order 1L780C. Otherwise, determine correct PSI**

### HMI MESSAGE PANEL SCREENS – Requires Engineering Programming

#### PART DESCRIPTION

#### PART #

HMI-140 Message Panel – 4 Line Display, 8 Programmable Keys – 4L523D	Retrofit Product
HMI-240 Message Panel – 4 Line Display, 20 Programmable Keys – 4L523B	OBSOLETE
HMI-750 Message Panel – Graphic Color Touch Screen – 4L523C-*	OBSOLETE

\*Replaced by the 4L523H

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 34

## OTHER PARTS (CONTINUED)

### HMI MESSAGE PANEL SCREENS – Graphic Color Touch Screen

PART DESCRIPTION	PART #
HMI-8046 Message Panel – Graphic Color Touch Screen – 4L523H The 4L523H replaces the 4L523 B,C,D,E,F,& G. Requires a new cable when replacing with a previous model. 4L523H-1 for PROTRONIX™ I, 4L536C-7 for PROTRONIX® II Controller)	Retrofit Product
Connection Cable-Connect the HMI to PROTRONIX® I-	4L523-1
Connection Cable-Connect the HMI to PROTRONIX® I-	4L536C-7

## HOODS

PART DESCRIPTION	NON-GASKET SIDE PART #	GASKET SIDE PART #
Fiberglass Hood 64" X 64" Non-Insulated *	87B186A	87B186B
Fiberglass Hood 64" X 64" Insulated *	87B295A	87B295B
Fiberglass Hood 72" X 72" Non-Insulated *	87B187A	87B187B
Fiberglass Hood 72" X 72" Insulated *	87B296A	87B296B
Hood, Pocket Pull Handle – 2 per hood side, 4 per station - Black		12L216A
Hood, Stainless Steel Lockable Draw Latch		12L233A
Hood Gasket, 64" X 156"		10L122AD
Hood Gasket, 72" X 172"		10L122AD
Louver, Adjustable 6" x 6"		11L138A

\* **NOTE:** Hardware is not included with the hood - must be requested separately.

## HOODS - MISCELLANEOUS PARTS

PART DESCRIPTION	PART #
Hood Roller Assembly (8 needed per hood)	87A301
S.S. External Retaining Ring	NPN
Roller – 1-1/2" diameter	87A258
Roller Stud	87B259
Roller Washer	87A359
Hood Roller Track – 62" (for 64" X 64" hood)	87B251A
Hood Roller Track – 70" (for 72" X 72" hood)	87B251B
Removable Track Stop – 4 required per station	87A279
Pocket Pull Hood Handle – 2 required per hood side, 4 per station – black	12L216A
Blower & Cord Assembly (includes blower, cord connector and 15' coiled cord)	87A414B
Air Discharge Seal (seals blower to hood)	87A86
Louver, Adjustable 6" x 6"	11L138A
Hood Gasket, 64" X 156"	10L122AD
Hood Gasket, 72" X 172"	10L122AD
Baseplate Gasket, 64" X 59"	10L122AB
Baseplate Gasket, 72" X 67"	10L122AB

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 35

## OTHER PARTS (CONTINUED)

### HOOD (FIBERGLASS) REPAIR KIT

PART DESCRIPTION	PART #
Fiberglass Hood Repair Kit (1 pt. S&L light green gel coat, 1 pt. Polyester resin, 3 sq. ft. fiberglass mat.)	CALL FACTORY

### KEYSTOCK (MOTOR SHAFT KEY)

PART DESCRIPTION	PART #
B Shaft	95L39-0
C Shaft	95L39-0
D Shaft	95L39-01

### LABELS

PART DESCRIPTION	PART #
Label, Blower	12A107A
Label, Rotation	12A152
Label, Motor No 1	12A2
Label, Motor No 2	12A3
Label, Low Level	12A537
Label, Low Water	12A538
Label, Notice Mechanical	12A74
Label, Notice Blower	12A76
Label, "OSHA" Warning	12L150AF
Label, "OSHA" Caution Lift Warning	12L150N
Label, S&L Logo 8" x 3-1/4"	12L154B
Label, S&L Logo 5" x 2"	12L154C
Label, Motor Lift Warning	12L166
Label, Control Panel Nameplate	12L170
Label, FORMULA X® Logo	12L217A

### LATCHES, FOR LOCKS

PART DESCRIPTION	PART #
Pad Lockable Draw Latch & Striker, S.S. (for hood)	12L233A
Pad Lockable Striker Plate & Latch, S.S. (for wet well access plates)	12L222A

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 36

## OTHER PARTS (CONTINUED)

### LEVEL INDICATION CONNECTION PLATE

PART DESCRIPTION	PART #
<b>Level Indication Connection Plate Complete Assembly</b> (includes all parts listed below)	H87A397
Float Switch Connection Plate Gasket	87B350
Float Switch Connection Plate	87B348
Pipe Plug (2 required for PROTRONIX® control panels, 3 required per plate for relay logic control panels)	1L69C
Cord Grip for Floats (3 required for PROTRONIX® control panels, 2 required per plate for relay logic control panels)	5L57C
Cord Grip for Submersible Pressure Transducer (1 required for PROTRONIX® control panels, 0 required per plate for relay logic control panels)	5L57N
Washer, Stainless Steel (2 required per plate)	6L65F
Lock Washer, Stainless Steel (2 required per plate)	6L94F
Hex Nut, Stainless Steel (2 required per plate)	6L30K
Label, Plastic – LL ALARM/TRANSDUCER/HL ALARM	12A538
Label, Plastic – LL OFF/LL ON/HL ON	12A537

### LIFTING STANCHION

#### PART DESCRIPTION

#### PART #

Lifting Stanchion – Top Section – Hemlock	87B39A2-304
Lifting Stanchion – Bottom Section – Hemlock	87B39B2-304

### LINE STRAINER

#### PART DESCRIPTION

#### PART #

Vapor Filter 12-Pack Replacement Part Kit Do not use with SONIC START® STREAMLINE™ or WaveStart®	H87A321A
---	----------

### LOUVER, VENT

#### PART DESCRIPTION

#### PART #

Louver, Adjustable – 6" x 6"	11L138A
Seal for Louver (Placed between louver & fiberglass)	87A86

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 37

## OTHER PARTS (CONTINUED)

### PAINT (VERSAPOX®) & TOUCH-UP KITS

#### PART DESCRIPTION

#### PART #

Touch-Up Paint Kit – Georgian Hemlock	H87A425
Primer (RED), Part A, Gallon	12L138A *
Primer Catalyst, Part B, Gallon	12L138B

\* Order one gallon of Catalyst Part B for each gallon of paint/primer – must be mixed before use.

### SHADE AIDE™ (HMI SCREEN SUN BLOCKER)

#### PART DESCRIPTION

#### PART #

SHADE AIDE™ Kit, Small (covers HMI Screen 9.5" W x 7" H)	H87A379-4
SHADE AIDE™ Kit, Small Stainless Steel (covers HMI Screen 9.5" W x 7" H)	H87A379-4X
SHADE AIDE™ Kit, Large (covers HMI Screen 15" W x 11" H)	H87A485-4
SHADE AIDE™ Kit, Large Stainless Steel (covers HMI Screen 15" W x 11" H)	H87A485-4X
SHADE AIDE™ Kit, Extra Large (covers HMI Screen 19.875" W x 14" H)	H87A503A-4
SHADE AIDE™ Kit, Extra Large Stainless Steel (covers HMI Screen 19.875" W x 14" H)	H87A503D-4X

### SLINGER RINGS (FOR MOTORS)

#### PART DESCRIPTION

#### PART #

B Shaft	95L39-B*
C Shaft	95L39-C*
D Shaft	95L39-D*

### VENT LOUVER

#### PART DESCRIPTION

#### PART #

Vent Louver, Adjustable – 6" x 6"	11L138A
-----------------------------------	---------

### VIDEOS - TRAINING

#### PART DESCRIPTION

#### PART #

How To Replace the Single Mechanical Seal – DVD Format	12L318DVD-1
--	-------------

\*PARTS ORDERING NOTE: Part # extension varied based on manufacturer. Motor manufacturer needs to be identified prior to sale.

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 38

## OTHER PARTS (CONTINUED)

### 4' WET WELL MANWAY ACCESS LIDS (ALUMINUM)

PART DESCRIPTION	PART #
4' Wet Well Manway Access Lid Half With Slot (aluminum)	87B184A
4' Wet Well Manway Access Lid Half Without Slot (aluminum)	87B184B
4' Wet Well S.S. Continuous Hinge (2 Required)	87B272B
Gasket (installs where two access lids mate up) U-Shaped Neoprene 4' required for 4' wet well	10L122AC
Neoprene Gasket (4' Wet Well Hinge) for Under Continuous Hinge (2 required)	87B182-2A
Center Support Angle	87B250C
Button Socket Headscrew (18 required)	6L221CD
SS Lock Washer (18 required)	6L94G
SS Hex Nut (18 required)	6L30A

### 5' & 6' WET WELL MANWAY ACCESS LIDS (ALUMINUM)

PART DESCRIPTION	PART #
5' & 6' Wet Well Manway Access Lid Half With Slot (aluminum)	87B184C
5' & 6' Wet Well Manway Access Lid Half Without Slot (aluminum)	87B184D
5' & 6' Wet Well S.S. Continuous Hinge (2 Required)	87B272D
Gasket (installs where two access lids mate up) U-Shaped Neoprene 5' required for 5' & 6' Wet Well	10L122AC
Neoprene Gasket for Under Continuous Hinge (2 required)	87B182-2B
Center Support Angle	87B250C
Button Socket Headscrew (23 required)	6L221CD
SS Lock Washer (23 required)	6L94G
SS Hex Nut (23 required)	6L30A

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 39

## VACUUM PRIMING SYSTEM

### FLOAT CHECK VALVES

#### PART DESCRIPTION

#### PART #

Float Check Valve, 3/8" NPT (Complete Assembly) (Replaces 1L443, 1L443G, and 87A76)	1L443H
Adapter Fitting, 3/8" x 1/4"	1L43D
Body (See drawing - not normally replaced)	
Ball Seat (for 1L443H)	1L443HA
Valve Ball 1 1/2" Diameter	1L443B
O-Ring (for 1L443H)	1L443HB
Bowl Only (for 1L443H) (Also includes O-Ring P/N 1L443B)	1L443HC
Drain Valve	1L333
<b>SONIC START® STREAMLINE™ and WaveStart® Float Check Valve</b> Piping Assembly (Connects Float Check Valve to vacuum tubing includes gauge port & shut off valve)	87B739

### SOLENOID VALVES

#### PART DESCRIPTION

#### PART #

2-Way Solenoid Valve (5/16" orifice)	1L545A
DIN Connector for 1L545A with 8' cord (OLD P/N: 1L545A-1) (Required for initial installation of 1L545A)	87A481-STK
2-Way Solenoid Valve Assembly for the <b>FORMULA X®</b> (Old Style Arrangement with Solenoid piped next to the Float Check Valve)	87B351
<b>SONIC START® STREAMLINE™ and WaveStart® Vacuum Dome /2-</b> Way Solenoid Valve Assembly-Newest Current Arrangement	87B728

### SONIC START® STREAMLINE™ KITS

#### PART DESCRIPTION

#### PART #

WaveStart® Upgrade Kit for One Pump from <b>SONIC START®</b>	H87A391M
WaveStart® Upgrade Kit for Two Pumps from <b>SONIC START®</b> -Must order 2 kits (Old P/N: H87A391B)	H87A391N
WaveStart® Upgrade Kit for One Pump from Electrodes	H87A391P
WaveStart® Drill & Tap Kit	H87A390A

### SONIC START® STREAMLINE™ PROBE

#### PART DESCRIPTION

#### PART #

<b>SONIC START® STREAMLINE™- 120 VAC (PROBE)</b>	4L628N
--	--------

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 40

## VACUUM PRIMING SYSTEM (CONTINUED)

### SONIC START® STREAMLINE™ REPLACEMENT PARTS

*These parts come standard in the SONIC START® STREAMLINE™ Kits*

PART DESCRIPTION	PART #
SONIC START® STREAMLINE™ Replacement Sensor Probe	4L628N
Explosion Proof SONIC START® STREAMLINE™ Prime Sensing Probe	4L628H
SONIC START® Operating Module	4L264
SONIC START® DIN Connector Cable (Old PN: 1L545A-2)	87A481-STK
SONIC START® 8 Pin Socket	5L49B
SONIC START® Cord Grip	5L57L
SONIC START® Cable Ties	5L150A
SONIC START® Brass Bulkhead Adapter	87A384
SONIC START® O-Ring for Bulkhead Adapter	11L4J
SONIC START® Jam Nut	6L222A
SONIC START® Reducer Coupling	1L552A
SONIC START® Male Tubing Connector	1L460D
SONIC START® O-Ring for Cord Grip	5L57L-2
SONIC START® Nut for Cord Grip	5L57L-1

### VACUUM DOME

PART DESCRIPTION	PART #
Vacuum Dome (one hole at top)	87B133B*
Compression Ring (holds dome in place)	87A226
SONIC START® STREAMLINE™ and WaveStart® Vacuum Dome /2-Way Solenoid Valve Assembly (Current Style)	87B728

**\*PARTS ORDERING NOTE:** Small O-Ring (P/N 11L4J) & Large O-Ring (11L4K) are recommended (not included with dome)

### VACUUM DOME ASSEMBLY

PART DESCRIPTION	PART #
Vacuum Dome Complete Assembly (one hole at top) Used with SONIC START® Probe. Old Style.	87B452A
DO NOT USE WITH SONIC START® STREAMLINE™ and WaveStart®	
Compression Ring (holds dome in place)	87A226
Ferrule Connection Fitting <i>(Optional replacement for Quick Disconnect Fitting on new style electrodes that are includes with these assemblies.)</i>	1L248A
Ferrule Nut & Sleeve	1L786A
SONIC START® STREAMLINE™ and WaveStart® Complete Vacuum Dome Assembly Vacuum Dome/ 2-Way Solenoid Valve Dome Assembly. Current Style	87B728

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 41

## VACUUM PRIMING SYSTEM (CONTINUED)

### VACUUM PUMP - HEAVY DUTY - SINGLE PISTON & SPARE PARTS

PART DESCRIPTION	PART #
Heavy Duty 1/6 HP (For Pumps with 4" Piping) ( <i>Complete pump</i> )	8L29
Repair Kit	8L29AB
Inlet Filter	8L29A1
Head Gasket	8L29A4
Valve Outlet	8L29A5
Valve Plate	8L29A6
Inlet Valve	8L29A7
Cylinder Gasket	8L29A8
Piston Ring	8L29A10
Piston Seal	8L29A11
Rider Ring	8L29A12
Fan	8L29A20
Shroud	NOT AVAILABLE**
Motor, 1/6 HP 1725	8L29A22
Vibration Isolator (See Section 6)	87A291

### VACUUM PUMP - HEAVY DUTY - DUAL PISTON & SPARE PARTS

PART DESCRIPTION	PART #
Heavy Duty 1/2 HP (For Pumps with 6" Piping) ( <i>Complete pump</i> ) (replaces 8L40A*)	8L32*
Repair Kit	8L32-1
Head Gasket	8L32-2
Outlet Valve	8L32-3
Inlet Valve	8L32-4
Cylinder Gasket	8L32-5
Felt	8L32-6
Piston Ring	8L32-7
Piston Seal	8L32-8
Rider Ring	8L32-9
Valve Plate	8L32-10
Motor 1/2 HP 1725 RPM	NOT AVAILABLE**
Shroud	8L32-12
Fan	8L32-13
Cylinder Head	8L32-14
Vibration Isolator (See Section 6)	87A291

\* SEE SECTION 6 FOR COMBINED EXHAUST CONFIGURATION

\*\*PURCHASE OF NEW 8L32 REQUIRED

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 42

## VACUUM PRIMING SYSTEM (CONTINUED)

### VACUUM PUMP - COMBINED EXHAUST ASSEMBLY

PART DESCRIPTION	PART #
Vacuum Pump	8L32
Tee	1L37C
Adapter	1L42B
Elbow	1L190H
Tube/NPT Connector	1L248D
Polyethelyne Tubing	1L142CA

### VACUUM TUBING

PART DESCRIPTION	PART #
Vacuum Tubing - 1/4"	Natural: 1L142AA Green: 1L142AB Red: 1L142AC
Vacuum Tubing - 3/8"	Natural: 1L142BA Green: 1L142BB Red: 1L142BC

### VACUUM TUBING FITTINGS (for vacuum domes, solenoid valves, & float check valves)

PART DESCRIPTION	PART #
Ferrule (old style) elbow - 3/8" x 1/4" NPT	1L190B
Ferrule (old style) straight - 3/8" x 1/4" NPT	1L248A
Ferrule Nut & Sleeve	1L786A
Quick Disconnect (new style) elbow - 3/8" x 1/4" NPT	1L546C
Quick Disconnect (new style) straight - 3/8" x 1/4" NPT	1L460D

### VAPOR FILTER

PART DESCRIPTION	PART #
Vapor Filter 12-Pack Replacement Part Kit - Recommend H87A391P <b>WAVESTART® Upgrade Kit</b>	
DO NOT USE H87A321A WITH SONIC START® STREAMLINE™ or WaveStart®	H87A321A

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 43

## VALVES

### PLUG VALVES

PART DESCRIPTION	PART #
4" Plug Valve	2L104A-304 *
Handle/Wrench Only for 4" Plug Valve (Chilean Red)	2L104AA1
4" Flange Gasket	11L1A
6" 3-Way Tapered Plug Valve	2L148M-304 *
6" Flange Gasket	11L1C
Valve Wrench for Plug Valves – (Chilean Red)	2L104AA1

\* **PARTS ORDERING NOTE:** 2 new Flange Gaskets per Plug Valve will be required.

### SOLENOID VALVES

PART DESCRIPTION	PART #
2-Way Solenoid Valve (5/16" orifice)	1L545A
DIN Connector for 1L545A with 8' cord (OLD P/N: 1L545A-1) (Required for initial installation of 1L545A)	87A481-STK
2-Way Solenoid Valve Assembly for the <b>FORMULA X®</b>	87B351
<b>SONIC START® STREAMLINE™ and WaveStart® Vacuum</b> Dome /2-Way Solenoid Valve Assembly	87A728

# ENGINEERING DATA



Smith &  
Loveless, Inc.®

14040 Santa Fe Trail  
Lenexa, KS 66215-1234, USA

After Market  
Parts Price Book  
Section 5  
Rectangular Recessed  
WWMPS Parts  
3/1/21 Page 44

## VALVES (CONTINUED)

### WAFER CHECK VALVES, SPRING LOADED

#### PART DESCRIPTION

#### PART #

4" Left Hand Wafer Check Valve, Extended Body	2L153S *
4" Right Hand Wafer Check Valve, Extended Body	2L153T *
4" Flange Gasket	11L1A
4" Check Valve Gasket	87A255
6" Check Valve Gasket	87A224
6" Left Hand Wafer Check Valve	2L153Q-304 *
6" Right Hand Wafer Check Valve	2L153R-304 *
6" Flange Gasket	11L1C

\* **PARTS ORDERING NOTE:** 2 new Gaskets per Wafer Valve will be required.

### WAFER CHECK VALVES – SPRING LOADED, SPARE PARTS

#### PART DESCRIPTION

#### 4" PART #

2L153S(-304) (LH)

2L153T(-304) (RH)

#### 6" PART #

2L153Q(-304) (LH)

2L153R(-304) (RH)

Seat Ring	11L207F	11L207G
Brass Arm *	55A32	55A39
Brass Clapper	55B39	55B29
Shoulder Bolt - Stainless Steel	6L184A	6L184B
Roll Pin - Stainless Steel	2L153A6	2L153C-12
Shaft - Stainless Steel *	55B32	55B37
Bronze Bushing ( <b>2 required</b> )	55A34	55A35
O-Ring ( <b>2 required</b> )	2L153A9	2L153C9
Steel Bar Arm/Handle	55A36	55A37
Pin - Stainless Steel	2L153D11	2L153A11
Eye Bolt (from body to spring)	6L55N	6L55N
Spring - Stainless Steel	11L104N	11L104M
Pipe Plug	1L69C	1L69D
Eye Bolt (from handle to spring)	6L55M	6L55M
Flange Gasket	11L1A	11L1C
Check Valve Gasket	87A255	87a224

\* **PARTS ORDERING NOTE:** 2 new Flange Gaskets per Plug Valve will be required.

### WRENCH, VALVE

#### PART DESCRIPTION

#### PART #

Valve Wrench for Plug Valve - Chilean Red	2L104AA1
---	----------